



## Electric Dryer Delivery Checklist

Is your home ready for your new electric dryer?

The checklist below will help you make sure your home is prepared for your new Samsung electric dryer and will ensure a smooth delivery and installation.



### Prior to Delivery:

- Be sure to **inspect your new electric dryer** before installation and again before the delivery team leaves.
- Verify unloading zone** is available within 30ft of the home for parking and access.
- Verify less than **three (3) flights of stairs** to get to the installation location (not applicable if elevator is available).
- An adult of **at least 18 years old**, authorized to make decisions, must be present for delivery.
- All appliances must be **empty of personal belongings** prior to removal.
- Measure the dimensions** (height, width, and depth) of the location where the unit will be placed. Make sure to measure at the top, middle, and bottom of the space, and the surrounding area and cabinets to ensure a suitable fit. **All dimensions can be found by model on the product page in the spec section.**



### Ventilation:

- A metal vent pipe is required** for proper dryer ventilation. Be sure to inspect your existing vent and also clean or remove anything that could block or clog the vent, such as built up lint.
- A semi-ridged ventilation duct could cause the dryer to stick out a couple inches compared to flexible ventilation ducting.

**\*Installers will not modify or alter the location or direction of your existing dryer vent, utilities, cabinets or countertops to complete installation.**



### Installation Location:

- Washers and dryers are able to be stacked but only when purchased and delivered together. A **Samsung stacking kit** (sold separately) is required for installation.

 **A grounded 220/240 volt outlet ready**

Make sure the location selected for your new dryer has a grounded, dedicated **220/240 volt electrical outlet**, protected by a **30 amp circuit breaker or a time-delay fuse**. Otherwise, an electrician will need to install the correct outlet before delivery.

**Pedestals must be purchased with your order**

Pedestals are a laundry accessory used to raise the height of washers and dryers. Pedestals cannot be installed unless the pedestal is purchased at the same time and on the same order as the dryer.

The installation team will not install a washer or dryer on an existing (old) pedestal.